



Fluid Alert - Customer Service: 844-700-8265

4.5 Battery Change Instructions for the ST 90

When it becomes necessary to change the batteries on the Series 90 unit please follow the instructions below:



ONLY use TankLink Battery Pack Part #394-00010

Failure to use the correct battery pack voids the warranty and use of another battery type or power source may present a risk of fire or explosion.

Open the lid by unscrewing the two screws to view the battery pack.



Unplug the battery cable from the connection and remove the Velcro from around the battery



Remove the batteries from the battery cradle by lightly pulling up on the battery pack.
Place your new battery pack into the cradle –
Reconnect the Velcro on top of the battery to secure it in place

Plug the battery cable back into the plug connection and press it firmly into place until you hear a click. The green LED light will begin to blink and power is restored to the unit. Close the lid and tighten down the two screws on the lid.

The following LED light sequence will be initiated once the battery is plugged in:

--A Green LED will begin to flash several times and eventually go solid. It will flash a few more time and then go out completely. The unit has been successfully installed and initiated.

NOTE: If you see a red light at any time during this sequence you will need to count the number of Green flashes immediately following the red light. This number will need to be provided to the Customer Support Team at 844-700-8265, in order to determine what error message the unit has provided.